

Moholock installation

You may have to trim off door capping rubber to install flat to the inside bodywork

Motorhome inside bodywork

Position lock 13mm down from edge of door opening
Temporary secure using tape then make sure lock clears the edge when opening locker, when satisfied secure using screws supplied.

Opening locker door

Moholock designed to be installed inside of locker or garage doors

Wire loom to control box secured by cable clips supplied

Cable Connector

